

HAYWARD®

Installation, Operation & Service Procedures Pool and Spa/Hot Tub Heaters

Models H250IDL & H400IDL


FOR YOUR SAFETY

WARNING: If the information in these instructions is not followed exactly, a fire or explosion may result causing property damage, personal injury, or death.

— Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.

WHAT TO DO IF YOU SMELL GAS

- Do not try to light any appliance.
 - Do not touch any electrical switch; do not use any phone in your building.
 - Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
 - If you cannot reach your gas supplier, call the fire department.
- Installation and service must be performed by a qualified installer, service agency or the gas supplier.



parts4heating
800-536-1582 Fax: 866-448-9304
info@parts4heating.com

Contents:

| | |
|--|-----------|
| SECTION I. GENERAL INFORMATION..... | 3 |
| Introduction..... | 3 |
| Hayward Heaters | 3 |
| Warranty..... | 3 |
| SECTION II. HEATER SIZING..... | 4 |
| Selecting The Correct Size Heater | 4 |
| For A Swimming Pool | 4 |
| For A Spa Or Hot Tub | 4 |
| SECTION III. INSTALLATION..... | 5 |
| Equipment Inspection..... | 5 |
| Conformance With Codes | 5 |
| Sea Level/High Altitude Installation..... | 5 |
| Location Of Heater..... | 5 |
| Flooring | 5 |
| Reversible Water Connections | 5 |
| Outdoor Installation And Venting..... | 6 |
| Indoor Installation And Venting..... | 7 |
| Air Supply..... | 7 |
| Equipment Located In Confined Spaces..... | 7 |
| Vertical Venting-Negative Pressure..... | 8 |
| Indoor Adapter Kit Installation | 8 |
| Vent Sizing Table..... | 9 |
| Horizontal or Vertical Venting-Positive Pressure | 10 |
| Special Gas Vent Adapter Kit Installation..... | 10 |
| Indoor Installation | 11 |
| Connecting Special Gas Vent to Heater..... | 11 |
| Gas Supply And Piping..... | 12 |
| Gas Pipe Size..... | 12 |
| All Gas Installations | 13 |
| Water Piping..... | 13 |
| Installation Above Pool/Spa Surface | 16 |
| Automatic Chlorinators And Chemical Feeders | 16 |
| Pressure Relief Valve | 16 |
| Electrical Connections | 17 |
| Remote Control Connection | 18 |
| Remote Thermostat Connection..... | 18 |
| Connecting a Remote..... | 18 |
| 2-Wire Remote Thermostat | 18 |
| 2-Wire Remote Switch..... | 18 |
| 3-Wire Remote Switch..... | 18 |
| SECTION IV. INSTALLER CHECK-OUT AND START-UP..... | 20 |
| General..... | 20 |
| Gas Line Testing | 20 |
| Gas Pressure Test Procedure | 20 |
| Installation Below Pool/Spa Surface | 22 |
| Two Speed Pump..... | 22 |

| | |
|---|--------------|
| SECTION V. CONSUMER OPERATION & MAINTENANCE PROCEDURES | 23 |
| General | 23 |
| Pool/Spa Water Chemistry | 23 |
| Using Chlorinators And Chemical Feeders | 23 |
| Heater Operation | 23 |
| Operating Instructions | 24 |
| Temperature Controls | 25 |
| Information Displayed..... | 25 |
| Heater Operation | 25 |
| Temperature Display | 25 |
| Diagnostics | 26 |
| Response To Faults | 26 |
| Periodic Inspection | 26 |
| Winterization | 27 |
| Opening Drain Valve | 27 |
| Spring Start-up | 27 |
| SECTION VI. QUALIFIED TECHNICIAN - MAINTENANCE/SERVICING..... | 28 |
| General | 28 |
| Maintenance | 28 |
| Control Access | 28 |
| External Heat Exchanger Inspection And Cleaning | 28 |
| Heat Exchanger Removal..... | 29 |
| Combustion Chamber | 29 |
| Internal Heat Exchanger Inspection And Cleaning | 29 |
| Burner Inspection And Cleaning..... | 29 |
| Burner Removal..... | 30 |
| Burner Installation..... | 30 |
| Gas Valve Replacement..... | 30 |
| Ignitor Removal..... | 31 |
| Main Burner Orifices..... | 31 |
| Gas Conversion | 31 |
| Control Locations | 31 |
| Electrical Wiring | 31 |
| Temperature Controls | 31 |
| Vent Pressure Switch..... | 31 |
| High Limits | 32 |
| Blower Vacuum Switch..... | 32 |
| Water Pressure Switch | 33 |
| Thermistor..... | 33 |
| By-pass Valve | 34 |
| Thermal Control Valve..... | 34 |
| Transformer..... | 35 |
| Combustion Blower | 35 |
| SECTION VII. TROUBLESHOOTING | 36-39 |
| PARTS LIST | 40 |
| PARTS ILLUSTRATION | 41 |
| WARRANTY & WARRANTY CARD..... | 42-43 |

Section I. General Information

Introduction:

This manual contains instructions for installation, operation, maintenance, troubleshooting and parts lists for the safe use of the Model H250IDL and H400IDL Low NO_x swimming pool/spa/hot tub heaters.

Hayward strongly recommends that the manual be read by the installer before installing the swimming pool/spa/hot tub heater. If after reviewing the manual, any questions still remain unanswered, contact the factory or local representative. Following heater installation, the installer should leave the manual with the consumer for future reference.

Hayward heaters:

The H-Series gas-fired pool/spa heater is the result of nearly 50 years in the engineering and production of the finest in water heating equipment. The direct fired finned-tube design of the pool/spa heater is the most advanced in the industry, offering highly efficient, economical pool/spa heating and scale free operation. No effort has been spared in making the pool/spa heater the most rugged, highly dependable, easy-to-maintain pool/spa heater available.

The H-Series heaters are suitable only for heating of swimming pools, spas, or hot tubs. These heaters should not be used as space heating boilers, general purpose water heaters, or for heating salt water pools and fish ponds. When installed and operated in accordance with the manual's instructions, the H-Series heater will provide many years of trouble-free service and increased pool/spa enjoyment.

The H-Series pool/spa heaters are so similar in design that many operating controls and other components are interchangeable. For this reason, the procedures in this manual pertain to both models unless otherwise noted.

Limited warranty summary:

We warrant the H-Series pool/spa heater to be free from defects in materials and workmanship, and we will, within two years from date of installation for single family residential users and one year for all other users, for the original purchaser, repair or, at our option, replace without charge any defective part.

We further warrant that if the heat exchanger or exchanger headers (water-containing section) leak within two years from the date of such installation for single family residential users and one year for all other users, due to defects in materials and workmanship, we will provide a replacement part.

Under the terms of the special FireTile™ limited warranty, we will replace any FireTile™ components used in the combustion chamber of the pool/spa heater which fail from defects in workmanship and materials under normal use and service in a single family residential application for a period of five (5) years.

Cost of freight, installation, fuel, and service labor (after one year) is at user's expense. For full details of warranty agreement, see warranty certificate included in this manual.

▲ CAUTION: If the pool/spa heater is damaged or destroyed by improper maintenance, excessive water hardness, incorrect water chemistry, or freezing, it is not covered under the manufacturer's warranty.


Section II. Heater Sizing

Selecting the correct size heater:

Factors influencing heater sizing include pool/spa size, average wind velocity, ambient temperature, and desired increase in temperature over ambient. A pool/spa in a warm area with little or no wind will not require as large a heater as one in a cool, windy location. Detailed sizing information is provided below.

For a swimming pool:

1. Determine pool's surface area in square feet. For indoor pool installations divide the pool's surface area by 3.



2. Determine desired pool water temperature (usually 78 - 82° F).
3. Determine average air temperature of coldest month of use.
4. The temperature rise is the difference between 2 & 3.

5. Locate in Figure 2 the surface area equal to or just greater than the pool's surface area and the temperature degree rise and select the appropriate heater model.

Figure 2 is based on 3 1/2 MPH wind velocity and elevation of up to 2,000 feet above sea level.

When not in use, keep pool covered to reduce heat loss, chemical usage, and dirt load on the filtering system.

For a spa or hot tub:

Determine spa capacity in gallons (surface area x average depth x 7 1/2).

The reference table lists the time required in minutes to raise the temperature of the spa/hot tub by 30° F. Locate in the table below the spa/hot tub size in gallons equal to or just greater than the spa/hot tub size in gallons. Select the desired time to raise the spa/hot tub temperature 30° F, read to the left and select the appropriate heater model.

This guide can be adjusted for other temperature rises. For example, if a 15° F increase in temperature is desired, simply divide the time for 30° F rise by the ratio of 30/15 = 2.

▲ NOTE: Heat losses and/or heat absorbed by spa walls (such as concrete) or other objects will add to the heat-up time.

Spa sizing is based on an insulated and covered spa. Always cover spa or hot tub when not in use to minimize heat loss and evaporation.

| Figure 2 - Recommended Heater Model | | | | | | |
|-------------------------------------|----------------------------------|------|------|------|------|------|
| Temp. Rise °F | 10° | 15° | 20° | 25° | 30° | 35° |
| Model | Pool Surface Area in Square Feet | | | | | |
| H250 | 2309 | 1540 | 1155 | 924 | 770 | 660 |
| H400 | 3695 | 2463 | 1848 | 1478 | 1232 | 1056 |

| Figure 3 - Recommended Heater Model | | | | | | | | | |
|-------------------------------------|---|-----|-----|-----|-----|-----|-----|-----|-------|
| Model | Spa/Hot Tub Size in Gallons | | | | | | | | |
| | 200 | 300 | 400 | 500 | 600 | 700 | 800 | 900 | 1,000 |
| | Time in Minutes to Raise Spa/Tub Temperature 30°F | | | | | | | | |
| H400 | 9 | 14 | 19 | 23 | 28 | 33 | 37 | 42 | 47 |
| H250 | 15 | 23 | 31 | 38 | 46 | 54 | 61 | 69 | 77 |

Section III. Installation

Equipment inspection:

On receipt of the heater equipment, inspect the heater carton for damage. If any carton is damaged, note it when signing for it. Remove the equipment from the carton(s) and advise the carrier of any damages at once.

Important notice:

The instructions herein are intended for the use of a qualified technician, specifically trained and experienced in the installation of this type of heating equipment. Some states or provinces require that installation and service people performing the installation be licensed. If this is the case in the state or province where heater is located, the contractor must be properly licensed.

▲ WARNING: Failure to comply with the appliance and vent package installation instructions and service instructions in this manual may result in equipment damage, fire, asphyxiation, or carbon monoxide poisoning. Exposure to products of incomplete combustion (carbon monoxide) can cause cancer and birth defects or other reproductive harm.

Conformance with codes:

The heater shall be installed in accordance with all local and state codes. The heater installation shall conform with the National Fuel Gas Code ANSI Z223.1 (latest edition) and with the requirements of the authority having jurisdiction. Design Certification of the heater is in compliance with ANSI Z21.56•CSA4.7.

For Canadian installations, the heater is to be installed in accordance with standards CAN/CGA-B149.1 and B149.2 – INSTALLATION CODES FOR GAS-BURNING APPLIANCES AND EQUIPMENT and/or Local Codes, and, if applicable, Standard CSA C22.1 – CANADIAN ELECTRICAL CODE, Part 1.

Sea level/high altitude installation:

The H-Series heaters may be installed up to 2,000 feet of elevation above sea level.

Location of heater:

Locate the pool/spa heater in an area where leakage of heat exchanger or connections will not result in damage to the area adjacent to the heater or to the structure. When such locations cannot be avoided, it is recommended that a suitable drain pan, with drain outlet, be installed under the heater. The pan must not restrict air flow.

This heater must be installed at least five feet from the inside wall of a pool/spa unless separated from the pool/spa by a solid fence, wall or other permanent solid barrier. This heater must be installed also at least five feet from the wall of an above-ground pool.

The heater must be installed such that the location of the vent assembly outlet relative to adjacent public walkways, adjacent buildings, openable windows, and building openings complies with the National Fuel Gas Code, ANSI Z223.1 and/or CAN/CGA B149 Installation Codes.

Flooring:

This heater can be installed on combustible flooring.

Reversible water connections:

This heater is designed so that it can be installed with the water connections located on either the right or left side. Heaters are shipped from the factory with the water connections on the right side. To bring the water connections to the left side, follow the step-by-step instructions below and refer to the illustration in Figure 5. These procedures should be performed by a trained service technician before the heater is installed.

1. Remove four main top screws and remove top.
 2. Remove side access covers.
 3. Remove heater main door.
 4. Disconnect high limit wires and reroute them to opposite side of heater. Disconnect thermistor leads from control panel and pull through intermediate panel.
 5. Remove pressure switch and tube.
 6. Remove drain valve and $\frac{3}{4}$ " brass plug and save for reinstallation.
 7. Remove 12 nuts retaining front header and carefully remove header.
- ▲ CAUTION:** By-pass and thermal governor may become dislodged when removing front heater. They must be reinstalled properly prior to reinstallation of front header.
- ▲ CAUTION:** Header O-rings may be reused if not permanently deformed. If installing new O-rings, Jack's 327 Lube may be liberally applied to O-rings to keep them in place during header installation.
8. Remove four screws retaining air deflector, and remove air deflector.
 9. Unplug wires and pressure tap tubes from combustion blower.
 10. Remove screws retaining flue collector and remove flue collector/combustion blower assembly.
 11. Remove screws securing heat exchanger from tube sheets.
 12. Lift out heat exchanger and rotate it 180 degrees horizontally – **DO NOT FLIP IT OVER.**





Figure 4

Reversible Water Connections
Figure 5



13. Reinstall front header on heat exchanger ("TOP" marking on header should now be on the bottom).
 14. Torque nuts from 5 to 7 ft. lbs. in the sequence shown in Figure 4. Install drain removed in step 6 on the bottom of the heat exchanger, install 3/4" brass plug on the top. Use new sealant on the threads of these parts before reinstalling. Do not overtighten.
 15. Move the pressure switch tube over to the left side of the heater and route through hole in intermediate panel. Insert tube in fitting and tighten the ferrule down with the nut.
 16. Reattach the high limit wires to the switches. Route thermistor leads through intermediate panel, into control compartment, and plug into control board.
 17. The remaining steps of reinstallation are the opposite of removal.
1. Outdoor models are self-venting and do not require additional vent piping.
 2. Do not install in a location where growing shrubs may in time obstruct a heater's combustion air and venting areas.
 3. Do not install this appliance under an overhang less than 3 feet from the top of the appliance. The area under the overhang must be open on three sides.
 4. Do not install heater where water spray from ground sprinklers can contact heater. Sprinkler water could cause operating problems.
 5. Do not install under a deck.
 6. Any enclosure around the heater must provide a combustion air vent commencing within 12 inches of the bottom of the enclosure. The vent opening shall have a minimum free area of 1 square inch per 4,000 BTU per hour of total input rating of all heaters in the enclosure. See Figure 7.

Outdoor installation and venting:

The following installation and service clearances must be maintained from surfaces to provide adequate air flow to the heater.

| Outdoor Installations |
|-------------------------------|
| Top - Open and unobstructed |
| Front - 24" |
| Back - 6" |
| Right side (Water side) - 12" |
| Left side - 6" |

Figure 6

| 1 Square Inch Per 4000 BTU Per Hour | | |
|-------------------------------------|-----------------|-----------------|
| Input | Combustion Air | Ventilation Air |
| 250,000 | 62.5 square in. | 62.5 square in. |
| 400,000 | 100 square in. | 100 square in. |

Figure 7

Indoor installation and venting:

The following installation and service clearances must be maintained from combustible materials.

| Indoor Installation |
|--------------------------------|
| Top - 36" |
| Front - Unobstructed |
| Back - 6" |
| Right side (Water side) - 12" |
| Left side - 6" |
| For use on combustible floors. |
| Do not install in a closet. |

Figure 8

Air supply:

Indoor installations and outdoor shelters must be provided with adequate combustion and ventilation air vents to assure proper heater operation. These vents must be sized according to the requirements stated in A. and B. in next column and must never be obstructed when heater is in operation.

When air blowers are used in spa/hot tub installations, caution must be observed to insure sufficient combustion air is available to the gas heater for proper combustion. A separate blower air duct is recommended.

Equipment located in confined spaces:

A. All Air Supply From Inside The Building: The confined space shall be provided with two permanent openings communicating directly with an additional room(s) of sufficient volume so that the combined volume of all spaces meets the criteria for an unconfined space (a space whose volume is not less than 50 cubic feet per 1000 BTUH). The total input of all gas utilization equipment installed in the combined space shall be considered in making this determination. Each opening shall have a minimum free area of 1 square inch per 1,000 BTU per hour of the total input rating of all gas utilization equipment in the confined space, but not less than 100 square inches. See Figure 9. One opening shall be within 12 inches of the top and one within 12 inches of the bottom of the enclosure.

B. All Air Supply From Outdoors: The confined space shall be provided with two permanent openings, one commencing within 12 inches of the top and one commencing within 12 inches of the bottom of the enclosure. The opening shall communicate directly, or by ducts, with the outdoors or spaces (crawl or attic) that freely communicate with the outdoors.

1. When directly communicating with the outdoors, each opening shall have a minimum free area of 1 square inch per 4,000 BTU per hour of total input rating of all equipment in the enclosure. See Figure 10.

2. When communicating with the outdoors through vertical ducts, each opening shall have a minimum free area of 1 square inch per 4,000 BTU per hour of total input rating of all equipment in the enclosure. See Figure 10.
3. When communicating with the outdoors through horizontal ducts, each opening shall have a minimum free area of 1 square inch per 2,000 BTU per hour of total input rating of all equipment in the enclosure. See Figure 11.
4. When ducts are used, they shall be of the same cross-sectional area as the free area of the openings to which they connect. The minimum dimension of rectangular air ducts shall be not less than 3 inches.

▲ NOTE: For more detailed methods of providing air for combustion and ventilation, refer to latest edition of the National Fuel Gas Code, ANSI Z223.1.

Figure 9

| 1 Square Inch Per 1000 BTU Per Hour | | |
|-------------------------------------|----------------|-----------------|
| Input | Combustion Air | Ventilation Air |
| 250,000 | 250 square in. | 250 square in. |
| 400,000 | 400 square in. | 400 square in. |

Figure 10

| 1 Square Inch Per 4000 BTU Per Hour | | |
|-------------------------------------|-----------------|-----------------|
| Input | Combustion Air | Ventilation Air |
| 250,000 | 62.5 square in. | 62.5 square in. |
| 400,000 | 100 square in. | 100 square in. |

Figure 11

| 1 Square Inch Per 2000 BTU Per Hour | | |
|-------------------------------------|----------------|-----------------|
| Input | Combustion Air | Ventilation Air |
| 250,000 | 125 square in. | 125 square in. |
| 400,000 | 200 square in. | 200 square in. |

Vertical Venting—Negative Pressure:


Locate the pool/spa heater as close as practical to a chimney or gas vent. See Figures 12 and 13. Size vent according to the venting tables. The maximum vent height should not exceed 50'. The total lateral vent length should not exceed one half of the total vertical vent height. The vent system can have up to three 90 degree elbows. See Figure 16 on page 9.

| Vent Collar Diameters | |
|-----------------------|----------|
| Model | Diameter |
| H250IDL | 6 pieds |
| H400IDL | 8 pieds |

The cap opening of the vent must terminate in accordance with Figure 16. The vent cap location shall have a minimum clearance of 4 feet horizontally from electric meters, gas meters, regulators and relief openings.

The weight of the vent or chimney must not rest on the heater. Support must be provided in accordance with the applicable codes. The vent pipe must be supported to maintain proper clearances from combustibles.

Venting extending above the roof by more than five feet should be guided or braced above or below the roof to protect the vent from wind and/or snow damage.




Indoor Adapter Kit Installation:

Before connecting vent to heater, a vent collar must be installed to the heater exhaust outlet, and a drain plug and outlet cover must be installed. These components are contained in the indoor Adapter Kit.


The installation of the kit is done as follows:

1. Remove the 4 screws that fasten the top to the internal vent assembly. Install the vent collar over



exhaust using 4 screws previously removed. See Figure 14.

2. Install plug into drain outlet at rear of heater. Install drain outlet cover over the drain outlet using 2 screws. See Figure 15.
3. Install vent pipe on the indoor vent collar. The collar will accept 6" or 8" vent diameter, depending upon the model of heater. See section titled "Indoor Installation and Venting" for indoor installation and venting guidelines.



Vent Sizing Table For Vertical Negative Pressure Venting

Figure 16


Table 1: Type B Vertical Vent with Type B Vent Connector
Lateral Length (L) must be less than 1/2 of the Vertical Vent Height (H)
Vent System can have up to three 90 degree elbows.

| Vent Diameter | H250IDL | | H400IDL | |
|---------------|--------------------|--------------------|--------------------|--------------------|
| | Minimum Height (H) | Maximum Height (H) | Minimum Height (H) | Maximum Height (H) |
| 6 in. | 8' | 50' | Not Recommended | Not Recommended |
| 7 in. | 6' | 50' | Not Recommended | Not Recommended |
| 8 in. | 6' | 50' | 6' | 50' |
| 9 in. | 6' | 50' | 6' | 50' |
| 10 in. | 6' | 50' | 6' | 50' |

Table 2: Type B Vertical Vent with Single Wall Vent Connector
Lateral Length (L) must be less than 1/2 of the Vertical Vent Height (H)
Vent System can have up to three 90 degree elbows.

| Vent Diameter | H250IDL | | H400IDL | |
|---------------|--------------------|--------------------|--------------------|--------------------|
| | Minimum Height (H) | Maximum Height (H) | Minimum Height (H) | Maximum Height (H) |
| 6 in. | 8' | 50' | Not Recommended | Not Recommended |
| 7 in. | 6' | 20' | Not Recommended | Not Recommended |
| 8 in. | Not Recommended | Not Recommended | 6' | 50' |
| 9 in. | Not Recommended | Not Recommended | 6' | 30' |
| 10 in. | Not Recommended | Not Recommended | Not Recommended | Not Recommended |

Table 1 is used when sizing Type B double-wall gas vent connected directly to the appliance.




Gas Vent Termination Table


| Roof Pitch | Minimum Height |
|---------------------|----------------|
| Flat to 7/12 | 1.0 Feet* |
| Over 7/12 to 8/12 | 1.5 Feet |
| Over 8/12 to 9/12 | 1.5 Feet |
| Over 9/12 to 10/12 | 1.5 Feet |
| Over 10/12 to 11/12 | 1.5 Feet |
| Over 11/12 to 12/12 | 1.5 Feet |
| Over 12/12 to 14/12 | 1.5 Feet |
| Over 14/12 to 16/12 | 1.5 Feet |
| Over 16/12 to 18/12 | 1.5 Feet |
| Over 18/12 to 20/12 | 1.5 Feet |
| Over 20/12 to 21/12 | 1.5 Feet |

*This requirement covers most installations

Table 2 is used when sizing a single-wall metal vent connector attached to a Type B double-wall gas vent.



The vent termination should not be less than 8 FT. from a vertical wall.



Horizontal or Vertical Venting—Positive Pressure:

The heater can be vented either horizontally or vertically with positive pressure vent system if one of the Special Gas Vent Systems listed in Figure 17 is used. Do not use a draft hood with this heater. The vent system must be installed in accordance with the National Fuel Gas Code ANSI Z223.1 or the CAN/CGA B149 Installation Codes, Local Codes, and the Vent Manufacturer's Instructions.

See Figure 17 for permissible vent diameters for these heaters.

See Figure 18 for maximum permissible vent lengths.

The Vent System must terminate with a Vent Terminal approved for this Pool Heater. See figure 19 for a list of approved vent terminals.

A Special Gas Vent Adapter Kit must be installed on heater before connecting the Special Gas Vent to the Heater.

Figure 17: Recommended Special Gas Vent Systems for Horizontal or Vertical Positive Pressure Venting of H250IDL & H400IDL Heaters

| Vent Brand | Manufacturer | Diameter |
|--|--|----------|
| Saf-T Vent Single Wall Special Gas Vent | Heat-Fab Inc. 130 Industrial Blvd. Turners Falls, MA 01376 (800) 772-0739 | 6" |
| Saf-T CI Vent Double Wall Special Gas Vent | | |

Figure 18: Maximum Special Gas Vent System Length for H250IDL & H400IDL Heaters

| Number of 90° Elbows | Maximum Length |
|----------------------|----------------|
| 0 | 50 |
| 1 | 50 |
| 2 | 40 |
| 3 | 30 |

Figure 19: Approved Special Gas Vent Terminals for H250IDL & H400IDL Heaters

| Vent Brand | Horizontal Terminal | Vertical Terminal |
|---------------|---------------------|-------------------|
| Saf-T Vent | 5690CI | 5600CI |
| Saf-T CI Vent | | |

Special Gas Vent Adapter Kit Installation:


A Special Gas Vent Adapter collar must be installed to the heater exhaust outlet, and a drain plug and outlet cover must be installed. These components are contained in the Special Gas Vent Adapter Kit.

The installation of the kit is done as follows:

1. Remove the 4 screws that fasten the top to the internal vent assembly. Install the vent adapter over exhaust using 4 screws previously removed. See Figure 20.
2. Install plug into drain outlet at rear of heater. Install drain outlet cover over the drain outlet using 2 screws. See Figure 21.


Special Gas Vent Adapter Installation

Figure 20



Drain Outlet Cover Installation

Figure 21



Indoor Installation:


The following installation and service clearances must be maintained from the heater to combustible materials. See Figure 22.

| Indoor Installation | Figure 22 |
|--------------------------------|-----------|
| Top - 36" | |
| Front - Unobstructed | |
| Back - 6" * | |
| Right side (Water side) - 12" | |
| Left side - 6" | |
| For use on combustible floors. | |
| Do not install in a closet. | |

* For installations in which the vent terminates in a wall directly behind the heater, allow 23" between the rear of the heater and the outside of the wall. See Figure 23.

Clearance for Vent Termination in Wall Directly Behind Heater

Figure 23




Connecting Special Gas Vent to the Heater:

Attach the Special Gas Vent to the Vent Adapter using the adhesive specified by the vent manufacturer. Do not drill holes or use screws to connect Vent to Vent Adapter.

1. Apply a bead of adhesive, about 1/8" in diameter, completely around the male end of the vent section, between 1/4" to 3/8" from the end of the section.
2. Fully insert the male section into the female fitting of the Vent Adapter.
3. Secure vent section to Vent Adapter by sliding the ring of the vent section over the tabs of the Vent Adapter and bending the tabs over the ring. See Figure 24.

Attaching Vent to Vent Adapter

Figure 24



Gas supply and piping:

Refer to the charts on Figure 25 for gas pipe sizing for low pressure natural gas, low pressure single stage propane gas, and high pressure two stage propane gas systems.

Gas pipe size:

Follow local gas codes for proper gas line material selection (copper, iron or plastic pipe, etc.)

LOW PRESSURE NATURAL GAS PIPE SIZING: (Based upon gas pressure of 0.5 psig or less and a pressure drop of 0.5 inch W.C.)

| DISTANCE FROM METER TO INLET OF GAS VALVE | MODEL | H250 | H400 |
|---|------------------|-------------------------|-------------------------|
| | BTU | 250,000 | 400,000 |
| | LINE MATERIAL | IRON OR PLASTIC PIPE | IRON OR PLASTIC PIPE |
| 0 to 50 feet | | 1" | 1¼" |
| 50 to 100 feet | | 1¼" | 1¼" |
| 100 to 200 feet | | 1¼" | 1½" |
| 200 to 300 feet | | 1½" | 2" |

LOW PRESSURE PROPANE GAS PIPE SIZING "SINGLE STAGE": (Based upon gas pressure of 11 inches W.C. inlet pressure at a pressure drop of 0.5 inch W.C.)

| DISTANCE FROM OUTLET OF TANK REGULATOR TO INLET OF GAS VALVE | MODEL | H250 | | H400 | |
|--|------------------|--------------|-------------|--------------|-------------|
| | BTU | 250,000 | | 400,000 | |
| | LINE MATERIAL | IRON PIPE | TUB- ING | IRON PIPE | TUB- ING |
| 0 to 50 feet | | 1" | 1⅝" | 1" | — |
| 50 to 100 feet | | 1" | 1⅝" | 1¼" | — |
| 100 to 200 feet | | 1¼" | — | 1¼" | — |
| 200 to 300 feet | | 1¼" | — | 1½" | — |

It is **VERY IMPORTANT**, when installing a propane heater on a two (2) stage regulation system, to follow the gas line sizing chart below—without exception.

HIGH PRESSURE "TWO STAGE" SYSTEMS:

HIGH PRESSURE PROPANE GAS PIPE SIZING "FIRST STAGE": (Based upon gas pressure of 10 psig inlet pressure at a pressure drop of 1 psi.)


| DISTANCE FROM OUTLET OF 1st STAGE REGULATOR TO INLET OF 2nd STAGE REGULATOR | MODEL | H250 | | H400 | |
|---|------------------|--------------|-------------|--------------|-------------|
| | BTU | 250,000 | | 400,000 | |
| | LINE MATERIAL | IRON PIPE | TUB- ING | IRON PIPE | TUB- ING |
| 0 to 50 feet | | ½" | ½" | ½" | ½" |
| 50 to 100 feet | | ½" | ½" | ½" | ⅝" |
| 100 to 150 feet | | ½" | ½" | ½" | ⅝" |

LOW PRESSURE PROPANE GAS PIPE SIZING "SECOND STAGE": (Based upon gas pressure of 11 inches W.C. inlet pressure at a pressure drop of 0.5 inch W.C.)

| DISTANCE FROM OUTLET OF 2nd STAGE REGULATOR TO INLET OF GAS VALVE | MODEL | H250 | | H400 | |
|---|------------------|--------------|-------------|--------------|-------------|
| | BTU | 250,000 | | 400,000 | |
| | LINE MATERIAL | IRON PIPE | TUB- ING | IRON PIPE | TUB- ING |
| 0 to 10 feet | | ½" | ¾" | ¾" | ⅝" |

Figure 25

Sediment Trap
Figure 26



All gas installations:

The H-Series heater is to be installed with a gas connection located on the left side. Insert the pipe to the gas valve through the grommet in the cabinet side. It is recommended that a ground-joint union be installed inside (or outside if space does not allow) the heater cabinet to facilitate servicing the burner assembly tray. See Figure 26.

A C.S.A. Certified main gas valve shutoff must be installed outside of cabinet and within 6 feet of the heater. Gas shutoff valve must have an I.D. large enough to supply the proper amount of gas volume to the heater.

▲ NOTE: Apply joint compounds (pipe dope) sparingly and only to the male threads of pipe joints. Do not apply joint compound to the first two threads. Use joint compounds resistant to the action of liquefied petroleum gas. Do not over tighten the gas inlet pipe or damage may result. See Figure 26.

To prevent dirt and moisture from entering gas valve, a sediment trap should be installed in the gas line close to the valve. See Figure 26.

Do not use flexible appliance connectors on any gas connections unless the connector is C.S.A. approved for outdoor installation, is marked with the BTUH capacity (which must be equal to or greater than the heater rated input), and the type of gas (Natural or LP) to be used.

Reduction of the gas supply pipe or tubing to the inlet of the heater gas valve must be made at the valve only and must match the valve inlet size ($3/4"$).

If more than one appliance is installed on the gas line, consult the local gas company for the proper gas line size.

Any questions concerning the installation of the proper gas line size can be directed to Hayward Technical Service. Call Hayward Technical Service at: Pomona, CA (909) 594-1600; Elizabeth, NJ (908) 351-5400; or Nashville, TN (615) 255-3111.

NATURAL GAS

The gas meter must have the capacity to supply enough gas to the pool heater and any other gas appliances if they are on the same pipeline (Example: 225 meter = 225,000 BTUH). If doubt exists as to the meter size, consult local gas utility for assistance. Hayward **will not** be responsible for heaters that soot up due to improper meter and gas line sizing resulting in improper gas volume.

PROPANE GAS

All propane gas tanks must be located outdoors and away from pool/spa structure and in accordance with the standard for storage and handling of propane gas, ANSI/NFPA 58 (latest edition) and applicable local codes. If propane gas tank is installed underground, the discharge of the regulator vent must be above the highest probable water level.

Propane tanks must be sufficient capacity to provide adequate vaporization for the full capacity of the equipment at the lowest expected temperatures. Consult a propane company expert for correct sizing.

▲ NOTE: Whenever a high pressure double regulation system is utilized for propane gas, consult a propane professional for accurate pipe and pressure sizing. Make sure that 1st and 2nd stage regulators are large enough to handle the BTUH input listed for the heater(s) being used.

Hayward **will not** be responsible for heaters that soot up due to improper gas line or propane tank sizing resulting in improper gas volume.

Water piping:

The H-Series heater is designed for use with pool and spa/hot tub water only, as furnished by municipal water distribution systems. The warranty does not cover heater use with mineral water, sea, salt, or other non-potable waters.

Do not install any restriction in the water pipe between heater outlet and pool/spa with the exception of a three-way switching valve and an

in-line chlorinator and associated check valve.
Blockage of water flow from heater return to pool may result in fire or explosion causing property damage, personal injury, or loss of life.


PLUMBING CONNECTIONS

1. The H-Series heater is equipped with CPVC SCH-80 flanged pipe nipples, union nuts, nitrile O-rings for use with 2" pipe connections. Figure 27 shows the method for installing these parts on the header.


▲ NOTE: Assemble these parts to heater prior to plumbing. Tighten union nuts securely before gluing fittings to ends of pipe nipples.

2. The CPVC SCH-80 flanged pipe nipples must be installed on the heater inlet and outlet without modification. CPVC SCH-80 plastic has an ASTM rating of F441 and is NSF approved. The opposite ends of the pipe nipples should be attached to the filtration system as particular installation dictates.
3. Pipe, fittings, valves, and any other element of the

Pipe Nipple Installation
Figure 27



Manual By-pass Valve
Figure 28



filter system may be made of plastic materials, if acceptable by the authority having jurisdiction. 1 1/2" plastic pipe if used, will slide directly into the flanged pipe ends.

4. Heat sinks (heat traps), fireman switches, and check valves are not necessary on the H-Series heaters. However, if there is any chance of "back-siphoning" of hot water when the pump stops running, it is suggested that a check valve be used on the heater inlet pipe.
5. The vari-flo by-pass that is built into the front header will maintain proper flow through the heat exchanger if the flow rate is within the range for the heater. See Figure 29.

RECOMMENDED FLOW RATE IN GPM

| Model | Minimum | Maximum |
|---------|---------|---------|
| H250IDL | 25 | 125 |
| H400IDL | 40 | 125 |


Figure 29

6. If the normal pump and filter system flow rate exceeds 125 gpm then a manual by-pass valve, as shown in Figure 28, must be installed as follows: Install a flow meter on the outlet line of the heater. Adjust the manual by-pass valve until the flow rate is within the rates required for the heater. Once the valve is set, the position should be noted and the valve handle removed to avoid further adjustment.
7. Figure 30 shows a typical pool piping diagram and layout for pool equipment. Figure 31 shows multiple heater usage for very large pools with and without an external by-pass (balancing) valve.

▲ **NOTE:** Improperly adjusted by-pass valves may result in damage to the heater; this damage is not covered under warranty.


Typical Plumbing To Pool

Figure 30



Multiple Heater Hookups

Figure 31




Installation above pool/spa surface:


If heater is installed less than three (3) feet above the surface of the pool/spa water, install eyeball fittings or directional flow fittings on the end of the return water line to the pool/spa to create adequate back pressure at the heater to operate the pressure safety switch when filter pump is running.

If heater is installed more than three (3) feet above surface of pool/spa water, install a loop as shown on Figure 32 to prevent drainage of water in heater during filter change.

For installation below pool/spa surface, refer to Section IV.




Automatic chlorinators and chemical feeders:



If used, a chlorinator must be installed downstream from the heater in the pool return line and at a lower elevation than the heater outlet connection. See Figure 33. Install a separate positive seal, corrosion resistant check valve between the heater outlet and chlorinator to prevent highly concentrated sanitizers from back-siphoning into the heater. Back-siphoning usually occurs when the pump is shut off and a pressure-section differential is created.


Pressure relief valve:

It may be necessary to install a pressure relief valve to conform with local building codes. A $\frac{3}{4}$ " pressure relief valve with a discharge capacity greater than or equal to the BTUH input of the heater and a pressure relief rating less than the heater working pressure is recommended (see rating plate).



A $\frac{3}{4}$ " NPT connection is provided in the front header for installation of a pressure relief valve. See Figure 34. The valve shall be installed directly to the header in a vertical position. To avoid scalding or water damage due to relief valve operation, connect a drain pipe to the valve outlet and run the line to a safe place of discharge. The drain pipe must be at least the same size as the valve discharge connection throughout its entire length and must pitch downward from the valve. No shutoff valve or restriction shall be installed between the relief valve and the discharge of the drainline. The valve lever should be lifted at least once a year to ensure that the waterway is clear.

Wiring Diagram Figure 35



Electrical connections:

The electronic ignition system is equipped with a Hot Surface Ignitor (HSI) used to automatically light the main burners on each call for heat. This control operates on 24 volts so an external power source is required.

All wiring connections to the heater must be made in accordance with the latest edition of the National Electrical Code ANSI/NFPA 70, unless local code requirements specify otherwise. In Canada, follow CSA C22.1 – CANADIAN ELECTRICAL CODE, Part 1.


Since an external electrical source is utilized, the heater, when installed, must be electrically grounded and bonded in accordance with local codes, or in the absence of local codes, with the National Electrical Code, ANSI/NFPA 70.

The H-Series heater must be installed with the electrical connections, service entry/remote control, located on the left side of the heater.

The heater is supplied with a single voltage transformer for a 240 volt power supply. If the heater is to be wired in series with the pump, the electrical circuit draws less than 12 amps. Use a 15 amp circuit breaker if heater is wired to a separate circuit.

Field wiring connections are to be made inside the junction box located behind the control access door. Refer to the wiring diagram and connect the power supply to the two black leads. See Figure 36. A ground wire is provided inside the junction box for connection of the field ground wire. Replace junction box cover and close access panel upon completion of field wiring.

Figure 35 shows the heater wiring for electronic ignition systems.



Remote control connection:

A terminal block is located near the electrical inlet. For remote thermostat control or remote on/off switching, connections are to be made to this terminal block.

Remote thermostat connection:

1. Connect the two remote wires to the two terminals on the terminal block labeled 'Remote Thermostat Connection'.
2. To operate heater by the remote thermostat, the #2 DIP Switch (located on the back of the circuit board) position must be moved to "On". This is the "Bypass" mode. Also, the control must be switched from "Standby" to "Pool" or "Spa".
3. While operating in the "Bypass" mode, the heater's thermostat is bypassed, the control will still function as a safety control by limiting the return water temperature to a maximum of 104° F.

Connecting a remote:

Remote wiring should be run in a separate conduit. Do not run remote wiring parallel to high voltage wires. For runs less than 30 feet, use 22 AWG wire. For runs over 30 feet, use 20 AWG wire. Runs should not exceed 200 feet.

The terminal block for connecting remote switches is located to the right of the electrical junction box. The electrical junction box is located on the left side of the heater. The dipswitch for disabling the heater's temperature thermostat is located on the circuit board. The setting of this dipswitch may need to be changed depending on the type of remote that is connected to the heater.

2-Wire remote thermostat:

This type of remote has its own temperature sensor for regulating the water temperature. To disable the heater's thermostat, set the bypass dipswitch to the "on" position. Wire the remote to terminals 1 & 2 of the terminal block. Do not remove the jumper clip on terminals 4 & 5.

To operate the heater by remote thermostat, the heater's control must be in either the "Pool" or "Spa" mode. The heater's display will show "bO". The "Pool" or "Spa" LED will be illuminated. The heater will fire when instructed by the remote thermostat. The heater's thermostat will function to limit the water temperature to a maximum of 104° F.

2-Wire remote switch:

This type of remote allows for the heater to be remotely turned off or on. The heater uses its internal thermostat to regulate the water temperature.

Connect this type of remote to terminals 4 & 5. Remove the jumper clip from 4 & 5. The bypass dipswitch should be kept in the off position.

The heater's internal thermostat will regulate the water temperature. Whenever the remote switch is off, heater will be disabled and the display will show "LO".

3-Wire remote switch:


A 3-wire remote allows for the "Pool" or "Spa" modes of the heater to be remotely selected. The heater uses its internal thermostat to regulate the water temperature.

Connect Pool/Low of the remote to terminal 1, Common to terminal 2, and Spa/High to terminal 3. Do not remove the jumper clip on terminals 4 & 5. The bypass dipswitch should be kept in the off position.


To operate the heater with a remote 3-wire switch, the heater's control must be in the "Standby" mode. The Standby LED will be illuminated. When the remote switch is set to "Pool/Low", the Pool LED will be energized and the display will show the water temperature. When the remote switch is set to "Spa/High", the Spa LED will be energized and the display will show the water temperature. The heater will use its internal thermostat to regulate the water temperature to the set point of the mode selected.

Connecting a remote:


Connection to 2-wire Remote Thermostat



Connection to 2-wire Remote On/Off Switch



Connection to 3-wire Remote



Section IV. Installer Check-out And Start-up

General:

Some of the following procedures will require the heater to be operating. Full lighting and shutdown instructions are included on the lighting instructions label secured inside the cabinet. The instruction label is shown in Figure 42. The heater is automatically lit on each call for heat.

Water must be flowing through the heater during operation. Check that the pump is operating and the system is filled with water and purged of all air prior to starting heater.

Gas line testing:

The appliance and its gas connection shall be leak tested before placing the appliance in operation. The heater and its individual shutoff valve must be disconnected from the gas supply piping system during any pressure testing of that system at test pressures in excess of 1/2 psig (3.45 kPa). The heater must be isolated from the gas supply piping system by closing its individual manual shutoff valve during any pressure testing of the gas supply piping system at test pressures equal to or less than 1/2 psig (3.45 kPa).

Gas supply line must be capped when not connected. After pressure testing, reconnect the gas piping to the gas valve. Turn gas supply on and test all pipe and tubing joints for leaks. Use a soap and water solution. Bubbles forming indicate a leak. **Never use an open flame (match, lighter, torch, etc.) as a leak could cause an explosion or injury.** Shut off gas and fix even the smallest leak right away. Be sure to leak test manifold fittings using above procedure once heater is in operation.

Gas pressure test procedure:

The following gas pressure requirements are important to the proper operation of the burners in gas heaters. Improper gas pressure or gas volume will create the following conditions:

1. Flame burns totally yellow.
2. Flame lifts off burner.
3. Heat exchanger soots up.


The pressure regulator on all H-Series heaters is preset at the factory and normally needs no adjustment. If gas pressure is inadequate, check for under-sized piping between meter and heater or for low capacity gas meter.

A. Gas pressure test procedure:

1. Obtain necessary equipment:
 - a. Manometer to read pressure in inches of water column.
 - b. 1/8" nipple (1/8" pipe thread x 1" long).
 - c. 3/16" Hex Wrench.
 - d. Screwdriver.

▲ SAFETY WARNING: Do not remove the 1/8" plug with the gas valve in the "ON" position. The gas valve must be in the "OFF" position when the plug is removed.


2. Remove 1/8" plug from gas valve.
3. Install 1/8" pipe nipple into gas valve.
4. Attach manometer to the 1/8" pipe nipple. See Figure 37.



5. Turn on water system and start heater following the lighting instructions on the label inside the cabinet. If there is more than just the pool/spa heater connected to the gas supply line, turn each of those appliances on while testing the heater.
6. Take pressure reading with the heater running. Propane gas must have 7" W.C. (water column pressure). Natural gas must have 2" W.C. See Figure 38.
7. If the gas pressure does not meet the above requirements the regulator must be adjusted.

Gas Pressure Reading

Figure 38



- B. Gas pressure regulator adjustment procedure:
 1. Remove access screw from the pressure regulator.
 2. Turn regulator adjustment screw clockwise to increase pressure and counterclockwise to decrease pressure. Replace access screw. See Figure 39.


▲ SAFETY WARNING: Do not remove the 1/8" pipe nipple with the valve in the "ON" position. The valve must be in the "OFF" position when the plug is removed.

3. Remove 1/8" pipe nipple and replace 1/8" plug. If proper pressure cannot be achieved by adjusting the regulator, the installer must contact the gas supplier and request that the inlet pressure to the heater be set as follows: Natural gas – 7" W.C., Propane gas – 11" W.C. The inlet gas pressure must not exceed 10.5" W.C. (water column pressure) for Natural gas or 13 W.C. for Propane gas. Exposure to higher pressures can damage the gas control valve, causing leaks or diaphragm rupture. This damage could result in fire, explosion, or burner overfiring leading to carbon monoxide poisoning. Minimum inlet gas pressure is 4.5" W.C. for Natural and 9" W.C. for Propane for the purpose of input adjustment.


ADJUSTMENT
SCREW

Valve Adjustment Screw

Figure 39



ACCESS SCREW




Installation below pool/spa surface:

1. Clean filter thoroughly.
2. Set heater thermostat to highest setting.
3. Start filter pump. Make sure all air is out of water lines and complete system is full of water.
4. Turn filter pump off, adjust pressure switch control. (See "Water Pressure Switch" on Page 33.)
5. Check pressure switch function by turning filter pump on and off causing heater to respond on or off. If heater is installed beyond pressure limits, a flow switch must be installed in water line to heater.

Heater Installation Below Pool

Figure 40



Two speed pump:

In a few cases, the pressure from a two speed pump is below the one pound minimum required to operate the heater. This is apparent when the pressure switch cannot be further adjusted. In these cases the pump must be run at high speed to operate heater. If the pump and piping arrangements are such that the required one pound minimum pressure cannot be obtained, do not attempt to operate the heater. Correct the installation.

Heater installation, check-out and start-up should now be completed. BE SURE to leave Installation, Operation & Service Procedures Manual with consumer.

Section V. Consumer Operation & Maintenance Procedures

FOR YOUR SAFETY – READ BEFORE OPERATING

General:

Water must be flowing through heater during operation. Check that the pump is operating and the system is filled with water and purged of all air prior to starting heater. In a new pool it is recommended that the filter be operated long enough to completely clean and clear the pool water and filter system.

Balance the pool/spa water chemistry and clean the filter. Then follow the instructions below.

Pool/Spa water chemistry:

See also Figure 41. The mineral content of swimming pool water increases daily due to addition of pool sanitizing chemicals and natural evaporation. Excess minerals will deposit on pool walls, in the filtration system, and in the heat exchanger tubes if the mineral content is too high.

Changing spa water regularly and maintaining correct chemical balance in pool/spa will keep the pool/spa safe and sanitary, and will protect heater and its warranty coverage. Purchase a good “DPD” water test kit and check the following chemical levels frequently:

CHLORINE OR BROMINE – Recommended level 1 to 4 ppm. Test before use.

pH – Recommended ideal level 7.4 to 7.6. **HIGH** readings reduce sanitizer efficiency. **LOW** readings are corrosive.

TOTAL ALKALINITY – 80 to 120 ppm. Test weekly during regular use. **LOW** readings are corrosive and cause rapid pH changes when chemicals are added.

CALCIUM HARDNESS – 200 to 400 ppm. Test whenever pool/spa is filled. **LOW** levels of hardness can be very corrosive.

Remember, addition of any chemicals can change levels of chlorine, pH, and total alkalinity.

It is recommended that residential spa water be changed every 2 to 3 months to prevent water problems. Public spas may need to have the water changed every week, or even daily, depending on bather load.

Using chlorinators and chemical feeders:

Follow the instructions provided with any automatic or manual chlorinator and chemical feeder. All chemicals must be introduced and diluted into the pool or spa water before being circulated through the heater. **Do not place chlorine tablets or bromine sticks directly into the skimmer.** High chemical concentrations may result when the pump is not running. High chemical concentrations will cause very rapid corrosion of the heat exchanger. Such damage is not covered under warranty.

Heater operation:

Full lighting and shutdown instructions are included on the lighting instructions label secured inside the cabinet. The instruction label is shown in Figure 42.

▲ WARNING: If you smell gas in the appliance area or near the floor (**PROPANE IS HEAVIER THAN AIR AND HENCE SETTLES ON THE FLOOR**), stop and follow instructions on the front cover. Since propane can accumulate in confined areas, extra care should be taken when lighting propane heaters. It is always a safe practice to keep your head well away from the lower firebox opening when lighting the heater.


▲ NOTE: Do not use the unit below 40° F temperature without adequate temperature protection. Do not operate heater while an automatic pool cleaner is in use unless the flow rate has been checked as correct under operation with the pool cleaner and a dirty filter.

Facts about water chemistry:

FACTORS which affect pool/spa water and, more importantly, the efficiency and operation of the pool/spa heater.

1. PROPER FILTRATION
2. PROPER CIRCULATION
3. DISINFECTION AND OXIDATION
4. pH CONTROL AND TOTAL ALKALINITY
5. ALGAE CONTROL

What is pH? It is the measure of the acidity or alkalinity of water. As shown on this chart, it is a critical measurement.



Hayward recommends using a four way test kit to obtain...

1. MIN./MAX. pH (7.2 - 7.8)
2. CHLORINE RESIDUAL (1.0 - 3.0 PPM), BROMINE (2.0 - 4.0 PPM)
3. TOTAL ALKALINITY (80 - 100 PPM) for calcium, lithium and sodium hypochlorite, or (100 - 120 PPM) for sodium dichlor, trichlor, and bromine.
4. CALCIUM HARDNESS (200 - 400 PPM)

Figure 41

FOR YOUR SAFETY READ BEFORE LIGHTING

WARNING: If you do not follow these instructions exactly, a fire or explosion may result causing property damage, personal injury or loss of life.

- This appliance does not have a pilot. It is equipped with an ignition device which automatically lights the burners. Do not try to light the burners by hand.
- BEFORE LIGHTING** smell all around the appliance area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle on the floor.

WHAT TO DO IF YOU SMELL GAS

- Do not try to light any appliances.
 - Do not touch any electric switch; do not use any phone in your building.
 - Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
 - If you cannot reach your gas supplier, call the fire department.
- Use only your hand to turn the gas control knob. Never use tools. If the knob will not turn by hand, don't try to repair it; call a qualified service technician. Force or attempted repair may result in a fire or explosion.
 - Do not use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the appliance and to replace any part of the control system and any gas control which has been under water.
 - Should over-heating occur, or the gas supply fails to shut off, turn off manual gas valve to the appliance.

POUR VOTRE SÉCURITÉ LIRE AVANT L'ALLUMAGE

MISE EN GARDE: Si vous ne suivez pas exactement ces instructions, un incendie ou une explosion pourrait survenir et causer des dommages à la propriété, des blessures corporelles ou la perte de la vie.

- Cet appareil n'a pas de pilote. Un mécanisme d'allumage automatique pour les brûleurs. N'essayer pas d'allumer les brûleurs à la main.
- AVANT L'ALLUMAGE**, sentir tout autour de l'appareil pour déceler d'éventuelles odeurs de gaz. S'assurer de sentir près du plancher parce que les gaz plus lourdes que l'air se concentrent au niveau du plancher.

QUE FAIRE EN PRÉSENCE D'ODEURS DE GAZ

- Ne pas essayer d'allumer l'appareil.
 - Ne pas toucher à un commutateur électrique; Ne pas utiliser le téléphone dans la maison.
 - Appeler immédiatement fournisseur de gaz chez un voisin. Suivre les instructions du fournisseur de gaz.
 - Si le fournisseur ne peut pas être atteint, appeler le service des incendies.
- Utiliser uniquement les mains pour actionner les boutons de commande du gaz. Ne jamais utiliser d'outils. Si le bouton ne s'enfonce pas ou ne se tourne pas à la main, ne pas essayer de le réparer. Appeler un technicien qualifié. L'utilisation de la force ou une tentative de réparation pourrait causer un incendie ou une explosion.
 - Ne pas utiliser cet appareil si une des composantes a été immergée dans l'eau. Appeler immédiatement un technicien qualifié pour vérifier l'appareil et remplacer toute composante du système de commande ou de gaz qui aurait été immergée dans l'eau.
 - Si le système surchauffait ou si le gaz refusait de se fermer, placer le robinet d'arrêt manuel de gaz de l'appareil en position ferme.

OPERATING INSTRUCTIONS

- STOP! Read the safety information on this label.
- Change the "MODE" on the control panel to "STANDBY."
- Remove the heater's front access panel.
- This appliance is equipped with an ignition device which automatically lights the burners. Do not try to light the burners by hand.
- Turn gas control knob clockwise to "OFF."
- Wait five (5) minutes to clear out any gas. If you then smell gas, STOP! Follow "B" in the safety information on this label. If you don't smell gas, go to the next step.
- Turn gas control knob counterclockwise to "ON."
- Replace the heater's front access panel.
- Set the "MODE" on the control panel to "SPA" or "POOL."
- Set the set point temperature on the control panel to the desired setting.
- If the appliance does not operate, repeat steps 2 through 10. If the appliance still does not operate, follow instructions "TO TURN OFF GAS TO APPLIANCE" and call your service technician or gas supplier.

GAS CONTROL
KNOB SHOWN
IN "OFF"
POSITION



TO TURN OFF GAS TO APPLIANCE

- Change the "MODE" on the control panel to "STANDBY."
- Remove the heater's front access panel.
- Turn gas control knob clockwise to "OFF."
- Replace the heater's front access panel.

INSTRUCTIONS D'ALLUMAGE

- STOP! Lire les consignes de sécurité sur cette étiquette.
- Changer le MODE du tableau de commande à STANDBY.
- Retirer le panneau d'accès avant de l'appareil de chauffage.
- Cet appareil est pourvu d'un dispositif d'allumage qui allume automatiquement les brûleurs. Ne pas tenter d'allumer manuellement les brûleurs.
- Tourner le bouton de commande du gaz en sens horaire à OFF (fermé).
- Attendre cinq (5) minutes que tout gaz se dissipe. Arrêter si l'on sent alors une odeur de gaz. Suivre B dans les consignes de sécurité de cette étiquette. Passer à l'étape suivante en l'absence d'odeur de gaz.
- Tourner le bouton de commande du gaz en sens anti-horaire à ON (ouvert).
- Replacer le panneau d'accès avant de l'appareil de chauffage.
- Régler le MODE du tableau de commande à SPA ou à POOL.
- Établir la valeur de réglage sur le tableau de commande à la température désirée.
- Si l'appareil ne fonctionne pas, répéter les étapes 2 à 10. Si l'appareil refuse toujours de fonctionner, suivre les instructions *Pour tourner le gaz à l'appareil* et appeler son technicien de service ou son fournisseur de gaz.

BOUTON DE
COMMANDE
DE GAZ MONTRÉ
EN POSITION
"FERMÉ" (OFF)



POUR FERMER LE GAZ SUR L'APPAREIL

- Changer le MODE du tableau de commande à STANDBY.
- Retirer le panneau d'accès avant de l'appareil de chauffage.
- Tourner le bouton de commande du gaz en sens horaire à OFF (fermé).
- Replacer le panneau d'accès avant de l'appareil de chauffage.

Figure 42

▲ Warning:

Do not ingest alcohol or drugs during use or prior to using pool, spa, or hot tub. Ingestion of such intoxicants can cause drowsiness which can lead to unconsciousness, and subsequently result in drowning.

Do not heat pool, spa, or hot tub water in excess of 104° F. A temperature of 100° F is considered safe for a healthy adult. Hotter water increases the risk of hyperthermia. Special caution is suggested for younger children.

Pregnant women beware! Soaking in water above 102° F (39° C) can cause fetal damage during first three months of pregnancy (resulting in the birth of a brain-damaged or deformed child). Pregnant women should adhere to the 100° F (38° C) maximum rule.

Before entering the spa or hot tub, users should check the water temperature with an accurate thermometer; spa or hot tub thermostats may err in regulating water temperatures by as much as four degrees Fahrenheit (2.2° C).

Persons with medical history of heart disease, circulatory problems, diabetes, or blood pressure problems should obtain their physician's advice before using spas or hot tubs.

Persons taking medications which induce drowsiness, such as tranquilizers, antihistamines, or anticoagulants, should not use spas or hot tubs.


If the pool/spa is used for therapy, it should be done with the advice of a physician. Always stir pool/spa water before entering the pool/spa to mix in any hot surface layer of water that might exceed healthful temperature limits and cause injury.

Do not tamper with controls, because scalding can result if safety controls are not in proper order.

Temperature controls:

Temperature Controls

Figure 43



The Hayward IDL heater has a temperature control that can be set to heat the pool and spa with independent temperature settings. The control also displays pool/spa water temperature and information to indicate that the heater needs service and diagnostic information for the service person.

Information displayed:

Information is displayed on an LED (light emitting diode) screen. The temperature control displays the water temperature of the pool or spa, as well as the

desired thermostat setting temperature, in either Fahrenheit or Celsius and the fault codes. Five LED's are also located on the control;

STANDBY – yellow LED, signifies control is “off”.

SPA – red LED, system is in SPA mode and maintains SPA set point.

POOL – red LED, system is in POOL mode and maintains POOL set point.

SERVICE – yellow LED, an abnormal condition has been detected.

HEATING – green LED, heating in process.

Return Water Temperature is displayed whenever the heater is operating and the UP or DOWN keys have not been pushed. If the heater is in “POOL” mode and the UP or DOWN key is pushed, the pool set point is displayed. If the heater is in “SPA” mode and the UP or DOWN key is pushed, the spa set point is displayed. If the “SERVICE” LED is lit, the control will continuously display the diagnostic code. If more than one diagnostic status is present, the display will flash each condition and repeat the sequence.

Heater operation:

To turn the heater on, toggle the “MODE” key to “POOL” or “SPA”. The Return Water Temperature will be displayed. To display the “POOL” or “SPA” set point, push the UP or DOWN key, the set point will flash. To change the “POOL” or “SPA” set point, continue to push either the UP or DOWN key until the desired set point is displayed for either “POOL” or “SPA”.

When the heater is initially started, the combustion blower will operate for approximately 40 seconds before the gas valve opens. The heater will then attempt to light, if ignition is successful, the blower will change from low speed to high speed after approximately 60 seconds and the “HEATING” light will come on. If ignition is unsuccessful, the combustion blower will continue to run for approximately 30 seconds, then the heater will recycle through two more ignition sequences. If after the third ignition sequence the heater fails to light, the heater will lockout for approximately one hour and a diagnostic code of “IF” will flash on the display. After one hour, the entire sequence will begin again. This entire process will continue indefinitely.

Temperature display:

The temperature can be displayed in either Fahrenheit or Celsius. To change to Celsius, move the position of the #1 “Dip Switch” (located on the back of the circuit board) to “C”.

Diagnostics:

If a problem is encountered during heater ignition or operation, the control will display a fault code(s). The codes are:

- bO** – Bypass operation
- SF** – Temperature sensor input failure.
- HS** – Maximum return water temperature exceeded.
- LO** – Limit string open.
- IF** – Ignition system lockout due to failed ignition.
- AO** – Open air pressure switch.
- AC** – Closed air pressure switch.
- PF** – Electrical polarity incorrect.
- HF** – False flame sense failure.

Response to faults:

Ignition system failure (IF) – After three retries, control locks out for one hour. SERVICE LED is energized. Blower shuts off after post-purge. Ignition failure fault code is displayed. Toggle control to STANDBY mode then to POOL or SPA mode to reset control.

Open limit string (LO) – Heating cycle terminated. Blower shuts off after post-purge. SERVICE LED is energized. Limit string open fault code is displayed. Control resumes normal operations once limit string closes.

Maximum return water temperature exceeded (HS) – If the measured return water temperature exceeds 104° F in either the Standard or Bypass operation modes, the heating cycle is terminated. Blower shuts off after post-purge. The SERVICE LED is energized. The maximum return water temperature exceeded fault code is displayed. The control resumes normal operation once the water temperature drops below 104° F.

Return water temperature sensor input failure (SF) – Heating cycle terminated. Blower shuts off after post-purge. SERVICE LED is energized. Sensor failure fault code is displayed. Control resumes normal operation once sensor input is restored.

Open air pressure switch during heating cycle (AO) – Heating cycle terminated. Blower continues to run. After 60 seconds, SERVICE LED is energized and open air pressure switch fault code is displayed. Control starts ignition sequence once pressure switch closes.

Open air pressure switch during ignition cycle (AO) – Control stops ignition sequence and waits for pressure switch to close. After 60 seconds, SERVICE LED is energized and open air pressure switch fault code is displayed. Control resumes ignition sequence once pressure switch closes.

Closed air pressure switch at beginning of ignition sequence (AC) – Blower does not run. Control waits for pressure switch to open. After 60 seconds,

SERVICE LED is energized and closed air pressure switch fault code is displayed. Control begins ignition sequence once pressure switch opens.

Loss of power – The resumption of power after a disconnection will result in the control returning to the mode it was in before the power loss and will recall the spa and pool set points.

False flame sense signal (HF) – Control locks out with blower operating on low speed continuously. SERVICE LED is energized and false flame sense signal fault code is displayed. Control resumes normal operation once false flame sense signal disappears.

Periodic inspection:

The H-Series is designed and built for long performance life when installed and operated according to the manufacturer's directions. Regular inspection by qualified service personnel is recommended to keep the heater operating properly. The following inspection points are suggested to help maximize heater life:

1. Periodically check the venting system on outdoor heaters. The heater's venting areas must never be obstructed in any way and minimum clearances must be observed to prevent restriction of combustion and ventilation air. Remember shrubs grow and in time may obstruct a heater's venting areas.
2. Check the venting on indoor heaters for looseness and possible leaks. Keep all openings for combustion and ventilation air clear and unobstructed.
3. Keep the entire pool heater area clean and free of all debris, combustible materials, gasoline and other flammable vapors and liquids. Remove any leaves or paper from around the heater.
4. Do not store chlorine, other pool chemicals, or other corrosives in the vicinity of the heater.
5. If heater is operating on Propane gas, Propane tank must not fall below 30% full or damage to the heater may occur. Hayward **will not** be responsible for heaters that soot up due to improper gas level in tank resulting in inadequate gas volume.
6. If another appliance is added to the gas line at a later date, consult local gas company to be sure the gas line will have the capacity to supply both units at full capacity at the same time.
7. Do not use the heater if any part has been under water. Contact a qualified service technician to inspect the entire heater and replace any part of the control system or gas valve that was under water. If heater has been totally submerged in water, replace the entire heater.
8. An inspection program is a good preventative maintenance measure. Keep this manual in a safe place for future reference and also for a service technician when inspecting or servicing heater. Additional inspection procedures to be performed

by a qualified service technician are covered in Section VI. of this manual.

Winterization:

In moderate climate, the heater can continue to operate during short term cold spells. Do not use the heater to maintain the water temperature just above freezing or for freeze protection. Care must be taken to avoid freeze-up in the heater. When it is used during freezing weather, the pump **must** run continuously. The heater is not warranted against freeze-ups.

In regions where freezing temperatures are encountered, all water **must** be drained from the heater when out of service, to prevent damage to the heater and piping. Draining heat exchanger is recommended as part of the season's shut-down procedures.

A HEATER DAMAGED BY FREEZING IS NOT COVERED UNDER THE MANUFACTURER'S WARRANTY.

Opening drain valve: (See Figure 44.)
(Above Pool Installations Only)

1. Turn heater thermostat(s) down to minimum setting. Set control to "STANDBY". Turn electricity off.
2. Turn heater gas valve to "OFF" position.


3. Turn manual gas valve outside of heater to "OFF" position.
4. Be sure circulating pump is off.
5. Open drain valve on front header and allow all water to drain from heater.
6. Leave drain valve open until spring start-up.

Spring start-up:

1. Inspect and clean heater, being sure heater is free of leaves and debris prior to startup.
2. Be sure inlet and outlet piping are properly attached to the unit and the drain valve is closed.
3. Turn filtration system pump on and allow system to run long enough to purge all air from the lines.
4. Turn manual gas valve outside of heater to "ON" position.
6. Set control to "POOL" or "SPA" position and set thermostat(s) to desired temperature setting. Keep water at a safe temperature.
7. If operating difficulties are encountered, contact a qualified service company for assistance.

Drain Valve Location

Figure 44



Section VI. Qualified Technician - Maintenance/Service

General:

▲ IMPORTANT: Only qualified service technicians, having appropriate test equipment, should be allowed to service the heater. Bear in mind that all of the components that comprise the system have an effect on the heater operation. Before proceeding with heater related troubleshooting tips covered in Section VII, be certain that the pump is operating correctly, the filters and strainers are not blocked, the valves in the piping are properly positioned, and the time clocks are properly set.

▲ WARNING: Do not attempt to repair any components of heater. Do not modify heater in any manner. To do so may result in a malfunction which could result in death, personal injury, or property damage. Check with consumer to see if any part of heater has been under water. Replace any part of the control system and any gas control which has been under water. Never use or attempt to use parts that have previously been used.

Maintenance:

The following inspection procedures are recommended to be performed as part of annual heater maintenance and to assure safe operation.

1. External heat exchanger.
2. Internal heat exchanger.
3. Main burner flame patterns.
4. Main burner orifices.
5. Operating controls.

Inspection procedures are covered below. Some of the procedures will require disconnecting and removing wires in the control compartment. See Control Access below.

Control Access:

Access to the operating controls is gained by removing the control panel on the front of the heater. See Figure 45.

1. Turn the two screws counterclockwise which secure the control panel door.
2. Open the control panel to access the operating controls.
3. **▲ CAUTION:** Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation.
4. Verify proper operation after servicing.
5. After servicing is complete, close control panel door and secure by turning screws clockwise.


External heat exchanger inspection and cleaning:

Inspect the external surfaces of the heat exchanger for soot accumulation. If soot has accumulated on the tubes it must be removed and its cause must be corrected.

Soot on a heat exchanger may be ignited by a random spark or open flame. To prevent this from occurring, dampen any soot deposits with a wet brush or water spray before servicing or cleaning the heat exchanger. The soot can be removed with a wire brush or a high velocity water spray after the heat exchanger has been removed. (See removal procedure below.) Although the heat exchanger should be cleaned of soot and reinstalled in the heater, the fact that sooting occurred should be investigated as it may be indicative of some other problems, such as:

- Insufficient air supply.
- Inadequate venting.
- High or low gas pressure.
- Blockage of secondary air openings.
- Improper location of heater.
- Incorrect gas supply pipe size.
- Excessive water flow through heat exchanger.
- Low LP tank (below 30% full).

Control Access
Figure 45



Heat exchanger removal:

1. Turn pump, main gas valve and heater power off.
2. Drain heat exchanger.
3. Remove four screws from vent in top of heater and remove top.
4. Remove access covers from both sides of heater.
5. Remove air deflector shield from around blower.
6. Unplug blower wire connector.
7. Disconnect air pressure tap tubes from blower/vent assembly.
8. Remove flue collector assembly.
9. Disconnect water pressure switch tube from header.
10. Disconnect high limit wires from header.
11. Lift heat exchanger assembly straight up off combustion chamber.
12. Installation is the reverse of removal.

Combustion chamber:

The combustion chamber is a “one piece” box. If damaged, the entire chamber must be replaced.

Internal heat exchanger inspection and cleaning:


The heat exchanger should be inspected periodically for the accumulation of lime scale on the interior surfaces of the tubes.

HEADER REMOVAL

1. Turn pump, main gas valve and heater power off.
2. Drain heat exchanger through drain valve on header.
3. Remove screws from left and right access panels and remove panels.
4. Remove wires from limit switches on header.
5. Remove thermistor from header.
6. Remove pressure switch tube from header.
7. Loosen union nuts and detach pool plumbing from header.
8. Remove the 12 washer-face nuts from header and remove header and O-ring. Inspect all 8 tubes of heat exchanger for any buildup of lime scale. If the heat exchanger needs to be cleaned, use the reaming or acid cleaning methods described below.

Heat Exchanger Tube Reaming

Figure 46



- A. Reaming:
This procedure does not require removal of the entire heat exchanger from the heater. The tubes may be reamed using a carbide-tipped reamer and a 1" wire brush. For easy reaming, dry the heat exchanger first and frequently retract the reamer to remove lime powder and prevent binding. See Figure 46.
- B. Acid Cleaning:
This procedure requires removal of the heat exchanger from the heater. Follow steps under “Heat Exchanger Removal”. The exchanger can be immersed in a muriatic acid solution (3 parts water to 1 part acid). The muriatic acid solution will remove some copper at a slow rate so care should be taken not to allow the exchanger to stay in the solution too long. When the tubes are clean, flush the assembly thoroughly with a soda-ash solution to neutralize any acid residue. If the tubes are pitted or worn thin, investigate and correct any hydraulic problems. Hydraulic problems may result from incorrect water chemistry, slow or excessive water flow, metals in the water, etc.

Reverse above procedures for reassembly. Use of a non-flammable lubricant on the mounting studs is recommended before reinstalling the washer-face nuts. Tighten washer-face nuts in a random pattern and torque each nut 65 to 75 in-lbs (5.50 to 6.25 ft-lbs). The amount of scaling depends upon the local water conditions and the severity of use. The tubes should be inspected after 60 days of operation and again after 120 days of operation. A routine inspection schedule can be developed based on the amount of scale deposits found in the tubes.

Burner inspection and cleaning:

With the heater on, remove the front door and make a visual inspection of the main burners. The main burner flames should be about 1/2 to 2 inches in height and should not “lift” off the ports of the burners. See Figure 47.

A normal flame is blue, without yellow tips. Yellow tips or a totally yellow or "lazy" flame may be an indication of a fuel-rich mixture due to restricted air openings, including spider nests in the burners and/or orifices.


All burners should be brushed with a wire brush and be free of lint, dust and spider webs before each season of use. Burners with damaged ports must be replaced.

Burner removal: (See Figure 48.)

1. Turn pump, main gas valve and heater power off.
2. Turn gas valve knob to "OFF" and toggle mode key to "STANDBY".
3. Remove wires and gas line from the heater gas valve.

Main Burner Flame Characteristics

Figure 47



4. Remove valve mounting bracket.
5. Remove burner manifold.
6. Remove the two screws securing each burner to the intermediate panel.
7. Pull burners out of heater.

Burner installation: (See Figure 48.)

1. Installation is the reverse of removal.
2. Turn on gas. Use a soapy water solution to check for leaks.
3. Bubbles forming indicate a leak. Never use an open flame (match, lighter, torch, etc.) as a leak could cause explosion or injury.
4. To start heater, follow the lighting instructions on the label inside the cabinet.


Gas valve replacement: (See Figure 48.)

▲ WARNING: Do not attempt to repair gas valve. If found to be defective, replace entire valve. Attempts to repair it will void the warranty.


1. Turn pump, main gas valve and heater power off.
2. Disconnect wires to gas valve.
3. Unscrew gas valve from manifold pipe.
4. Replace gas valve. Only use liquid pipe dope on the male threads of the manifold. Do not place pipe dope on the first two threads of the pipe.
5. Reconnect wires to gas valve.

Burner Removal

Figure 48



Ignitor Removal
Figure 49



Ignitor removal: (See Figure 49.)

▲ WARNING: Ignitor is fragile.

1. Disconnect ignitor wires.
2. Remove two screws retaining ignitor.
3. Carefully remove ignitor from combustion chamber.

Main burner orifices:

The main burner orifices can be removed from the manifold with a $\frac{7}{16}$ " wrench without having to remove the burner assembly from the heater. After cleaning or replacing orifices re-install in manifold being careful not to overtighten as a leak may result.

▲ CAUTION: Do not enlarge orifice holes.

Gas conversion:

The factory installed gas train, where appropriate, may be changed from natural gas to propane or from propane to natural gas, using the appropriate conversion kit, available from the factory. Gas conversions are to be performed only by a qualified agency. Detailed instructions are included with each kit.

▲ NOTE: Conversion kits are not available in Canada. Conversions must be done by the conversion station at Hayward Pool Products Canada, Inc.

Control locations:

The following sections give a brief overview of the various heater controls and service/replacement procedures. The text describes the intended purpose of the controls. See Figure 50 for general location of the controls.

Electrical wiring:

▲ NOTE: If it is necessary to replace any of the original wiring, it must be replaced with No. 18 AWG UL or CSA approved wire rated at 105° C and 600V.

Temperature controls:

The control is an integrated thermostat and ignition control which operates the heater. The replacement part is available as an assembly only.

To remove control panel assembly:

1. Unplug six wire plugs from the rear of the circuit board.
2. Remove four screws retaining the plastic bezel to the sheet metal.
3. Pull entire assembly through the front panel.


Installation is the reverse of removal.

Vent pressure switch:

The vent pressure switch will not allow the heater to continue to operate if the indoor vent becomes blocked.

To replace switch:

1. Turn pump, main gas valve and toggle mode switch to "off".
2. Turn electricity off.
3. Open control panel door.
4. Remove wires, screws and tubing from the switch.
5. Replace with new switch and reverse the above procedures.




High limits:

The high limit is an automatically resetting safety device wired in series with the thermostat, pressure switch and main gas valve. See Figure 50. The pool heater is equipped with two automatic high limits. The limits are located on the header.

▲ CAUTION: The two limit switches have different temperature settings (check Parts List).

High Limit
Figure 51



If the water temperature at the location of the limit should exceed the limit set point, the main gas valve will shut off gas supply to the burners.

An erratic high limit is often an indication of a problem with water flow. Reduced flow may be caused by:

1. Clogged filter or strainer.
2. Excessive flow through the external bypass valve if one is used.

3. Lime scale accumulation in the heat exchanger.


To replace high limits:

1. Turn pump, main gas valve and heater power off.
2. Turn electricity off.
3. Drain heat exchanger of all water.
4. Remove side access panels.
5. Remove wires from high limits.
6. Unscrew the defective high limit.
7. Replace the high limit and reverse above procedures.

Blower vacuum switch:

The blower vacuum switch will not allow the heater to operate unless the combustion blower is operating.

Blower Vacuum Switch
Figure 52



To replace switch:

1. Turn pump, main gas valve and heater power off.
2. Turn electricity off.
3. Open control panel door.
4. Remove wires, screws and tubing from the switch.
5. Replace with new switch and reverse the above procedures.

Water pressure switch:


The pressure switch (Figure 53) is preset at the factory for deck level installations. When the heater is located below the level of the spa or pool, the pressure switch may require an adjustment to compensate for the no-flow static head. The following procedure is recommended when the switch needs adjustment and/or is replaced:

1. Be sure the filter is clean before making the adjustment.
2. With the pump and heater mode switch on, turn the adjustment dial on the pressure switch clockwise, until a click is heard from the gas valve.
3. Turn the adjustment dial counterclockwise $\frac{1}{4}$ turn.
4. Turn the pump off and on several times. The heater should shut off immediately when pump is shut off. If the heater fails to shut down with pump, repeat the steps above until the switch is adjusted properly.

▲ CAUTION: Do not operate the pool heater without the function of a properly adjusted pressure switch or flow switch.

To replace pressure switch:


1. Turn pump, main gas valve and heater power off.
2. Turn electricity off.
3. Open header drain and drain heat exchanger of all water.
4. Remove heater front door.
5. Remove wires from pressure switch.
6. Using two $\frac{1}{2}$ " open end wrenches disconnect the pressure switch from pressure switch tube.
7. Replace pressure switch and reverse above procedures. Use new sealant on pressure switch threads before reinstalling.
8. Check for any possible leaks after start-up of unit.

Pressure Switch**Figure 53****Thermistor:**

The thermistor monitors the return water temperature.

To replace pressure thermistor:

1. Turn pump, main gas valve and heater power off.
2. Turn electricity off.
3. Drain heat exchanger of all water.
4. Remove side access panels.
5. Disconnect thermistor leads from circuit board.
6. Unscrew the thermistor.
7. Replace the thermistor and reverse above procedures.

Thermistor**Figure 54**

By-pass valve:

The header houses an automatic by-pass valve. The valve provides proper water flow through the heat exchanger as the filter system water pressure varies. The valve assembly consists of a plunger, a spring, and a shaft. The plunger glides along the shaft as system water pressure compresses the spring. Very high acid or chlorine concentrations may damage the valve parts or very hard water may leave deposits on the shaft causing the valve to stick. If the valve sticks open, very little water will pass through the heat exchanger causing overheating and possibly opening the high limit contacts. If the valve sticks closed, too much water will flow throughout the heat exchanger causing condensation to occur. Either situation may result in insufficient heating of the pool or spa.

To replace valve parts:

Drain heat exchanger of all water. The valve may


be removed as shown in Figure 55. The plug on the right side of the header is unscrewed and the shaft and spring are pulled out. The plunger can be removed through the outlet port of the header after the pool plumbing is disconnected from the heater. Re-install by reversing above procedure.

Thermal control valve:

The header also houses a thermal control valve. This valve helps to control condensation off the heat exchanger by not allowing water to flow through the heat exchanger until the water reaches a temperature of 105°F. Very hard water may leave deposits on the valve plunger causing the valve to stick. If the valve sticks open, cold water can flow through the heat exchanger causing condensation to occur. If the valve sticks closed, very little water will flow through the by-pass hole which will open the high limit contacts.


By-pass Valve

Figure 55



Thermal Control Valve

Figure 56



To replace thermal control valve:

1. Follow the instructions on page 27 for header removal only.
2. Remove the plastic by-pass insert from header.
3. Remove the thermal control valve from header.
4. Test the thermal control valve by placing it into a hot water bath (above 108° F) and watching for movement that compresses the spring and opens the annular area in the center of the valve. If this action does not take place, replace the valve with a new one that has been tested as above. See Figure 56.
5. Reverse the procedures for reassembly.

Transformer:

The transformer reduces the main power supply of 240V down to 20 - 26 volts. This is the voltage range in which the heater operates.

To replace the transformer:

1. Turn pump, main gas valve and heater power off.
2. Remove two screws and open front control panel.
3. Disconnect two slip-on terminal wires from the transformer.
4. Detach main power wires from transformer.
5. Remove the screws securing transformer to the mounting bracket and remove transformer.
6. Replace the transformer and reverse the above procedures.

Rewire according to the wiring diagram on the heater.

Combustion blower:

The combustion blower provides the air that mixes the gas from the main burners for the combustion process. On initial start-up, the blower operates for 40 seconds to purge gas out of the heater. Then, the main gas valve opens for a period of 7 seconds and the heater lights. The blower operates the entire time the gas valve is open and for 30 seconds after the valve closes.

To replace the combustion blower:

1. Turn pump, main gas valve and heater power off.
2. Remove main top.
3. Disconnect wires and hoses attached to the blower.
4. Remove air deflector.
5. Remove screws attaching blower to flue collector.
6. Remove vent from blower.
7. Replace blower.
8. Reverse the above procedure for installation.

Section VII. Troubleshooting

General:

▲ NOTE: These instructions are intended for the use of qualified personnel trained and experienced in the installation and servicing of this type of heating equipment and its related system components. Some states may require installation and service personnel to be licensed. Persons not qualified should not attempt to repair this equipment according to these instructions.

▲ WARNING: Never leave a jumper wire connected to keep a heater running. A jumper wire should be used as a test device only, as it is not a cure for a defective control.

▲ CAUTION: Never allow the main burner to operate more than five seconds with the filter system shut off. Serious damage to the heater will result. Anytime the heater bangs or knocks, it indicates a water void or lack of water flow. Shut off heater immediately if this occurs.

▲ Wiring:

As a preliminary check, make sure that all wire connections are clean and tight and that all wiring conforms to the wiring diagrams See Figures 35 and 36.

Troubleshooting Chart

IDL Heater Diagnostic Guide

| Code | Fault | Diagnosis Step | Remedy |
|------|---------------------------------|---|--|
| BO | Bypass operation. | 1. Check state of #2 dip switch on back of control module. | This is a normal display when heater is being controlled by a remote thermostat. No service is required. If heater is not being controlled by remote thermostat, change setting of #2 dip switch to "Off" position. |
| LO | Water pressure switch fault. | 1. Verify that pump is running. | This is a normal display when the pump is off. Turn pump on. LO code should clear. If LO does not clear, proceed to step 2. |
| | | 2. Check for faulty wiring or connection. | Inspect water pressure switch wiring. Ensure wire harness terminals are securely fastened to spade terminals on water pressure switch. If OK, proceed to step 3. |
| | | 3. Verify state of water pressure switch contacts. | Remove wire leads from water pressure switch and jumper leads. Measure continuity across water pressure switch with pump on. If closed, LO code is not caused by water pressure switch fault. If open, proceed to step 4. Remove jumper from wire leads and reconnect wire leads to water pressure switch. |
| | | 4. Ensure that low pump pressure does not exist. | Clean filter or clear blockages. Check position of valves in plumbing system. If OK, proceed to step 5. |
| | | 5. Check for correct water pressure switch setting. | Adjust water pressure switch setting per installation manual. If LO does not clear, proceed to step 6. |
| | | 6. Water pressure switch is defective. | Replace water pressure switch. |
| | Terminal block fault. | 1. Check if a remote on/off device connected to terminal block is open. | This is a normal display when a remote on/off device operates to shut the heater off. Turn remote device on. LO code should clear. If LO does not clear proceed to step 3. If a remote on/off device is not connected to heater proceed to step 2. |
| | | 2. Check if jumper has been removed. | If remote on/off control is not used, the two far-right terminals of terminal block should be jumpered. Verify jumper is present. If not, add jumper. If LO code does not clear, proceed to step 3. |
| | | 3. Check for faulty wiring or connection. | Inspect terminal block wiring. Ensure wire harness terminals are securely fastened to terminal block. If OK, proceed to step 4. |
| | | 4. Terminal block is defective. | Replace terminal block. |
| | Vent pressure switch fault. | 1. Check for faulty wiring or connection. | Inspect vent pressure switch wiring. Ensure wire harness terminals are securely fastened to spade terminals on vent pressure switch. If OK, proceed to step 2. |
| | | 2. Verify state of vent pressure switch contacts. | Remove wire leads from vent pressure switch and jumper leads. Operate heater. Measure continuity across vent pressure switch. If closed, LO code is not caused by vent pressure switch fault. If open, proceed to step 3. Remove jumper from wire leads and reconnect wire leads to vent pressure switch. |
| | | 3. Check for restricted or blocked flue. | Ensure that flue is not blocked or restricted. See indoor vent sizing requirements in installation manual. If OK, proceed to step 4. |
| | | 4. Vent pressure switch is defective. | Replace vent pressure switch. |
| | Temperature limit switch fault. | 1. Check for faulty wiring or connection. | Inspect temperature limit switch wiring. Ensure wire harness terminals are securely fastened to spade terminals on temperature limit switches. If OK, proceed to step 2. |
| | | 2. Verify state of temperature limits' contacts. | Remove wire leads from limit switch and jumper leads. Operate heater. Measure continuity across limit switches. If closed, LO code is not caused by temperature limit switch fault. If open, proceed to step 3. Remove jumper from leads and reconnect leads to temperature limits. |
| | | 3. Verify that water flow is adequate. | Verify that water flow rate to heater is above minimum required (25 GPM for H250IDL, & 40 GPM for H400IDL). If OK, proceed to step 4. |
| | | 4. Temperature limit switch is defective. | Replace temperature limit switch. |

Troubleshooting Chart

IDL Heater Diagnostic Guide

| Code | Fault | Diagnosis Step | Remedy |
|------|-----------------------------------|--|---|
| IF | Ignition failure. | 1. Ensure gas supply shutoff valves are open. | Ensure that main gas shutoff installed adjacent to heater is open. Ensure that knob on gas valve inside unit is in on position. If OK, proceed to step 2. |
| | | 2. Check for low gas supply pressure. | Ensure inlet gas supply pressure exceeds minimum value indicated on rating plate. If OK, proceed to step 3. |
| | | 3. Check for faulty flame sense wiring or connection. | Inspect flame sense wiring. Ensure wire harness terminals are securely fastened to flame sense and to control module. If OK, proceed to step 4. |
| | | 4. Check for faulty igniter wiring or connection. | Inspect igniter wiring. Ensure igniter plug is securely fastened to wire harness plug. Ensure plug on wire harness is plugged into back of control module. If OK, proceed to step 5. |
| | | 5. Check for faulty gas valve wiring or connection. | Inspect gas valve wiring. Ensure wire harness terminals are securely fastened to spade terminals on gas valve. If OK, proceed to step 6. |
| | | 6. Check for igniter failure. | Disconnect igniter plug from harness. Measure continuity across igniter. If open, igniter is broken or defective. Replace igniter. Otherwise, proceed to step 7. Reconnect igniter plug to harness. |
| | | 7. Check for aged igniter. | Measure igniter amp draw with clamp-on amp meter during igniter warm-up period. Igniter should draw a minimum of 2.0 amps at 240 vac. If not, replace igniter. If OK, proceed to step 8. |
| | | 8. Check for failed igniter relay. | Disconnect igniter plug from receptacle in control module. Measure voltage across receptacle pins during igniter warm-up. If 240 vac is not present, igniter relay on control module is defective. Replace control module. If OK, proceed to step 9. |
| | | 9. Check for gas valve failure or gas valve relay failure. | 1. Measure voltage across gas valve during trial for ignition. If 24 vac is present and gas valve does not open, gas valve is defective. Replace gas valve. 2. If 24 vac is not present, gas valve relay on control module is defective. Replace control module. |
| SF | Temperature sensor input failure. | 1. Check for faulty wiring or connection. | Inspect sensor wiring. Ensure sensor is plugged into back of control module. If OK, proceed to step 2. |
| | | 2. Sensor is defective. | Replace temperature sensor. |
| AC | Blower vacuum switch closed. | 1. Check for defective blower on relay on control module. | Disconnect high voltage plug from harness. With heater off, measure continuity across L1 and IND LO and across L1 and IND HI pins on control module. If either pair is closed, control module relay is defective. Replace control module. If OK, proceed to step 2. |
| | | 2. Vacuum switch is defective. | Replace blower vacuum switch. |

Troubleshooting Chart

IDL Heater Diagnostic Guide

| Code | Fault | Diagnosis Step | Remedy |
|------|--|---|--|
| AO | Blower vacuum switch open | 1. Check for faulty vacuum switch tubing. | Check tubing and replace if necessary. If OK, proceed to step 2. |
| | | 2. Check for faulty vacuum switch wiring or connection. | Inspect vacuum switch wiring. Ensure wire harness terminals are securely fastened to spade terminals on vacuum switch. If OK, proceed to step 3. |
| | | 3. Check for faulty blower wiring or connection. | Inspect blower wiring. Ensure plug on blower is securely fastened to wire harness plug. Ensure high voltage plug on wire harness is plugged into back of control module. If OK, proceed to step 4. |
| | | 4. Check for defective vacuum switch. | Disconnect leads from blower vacuum switch. Check for continuity across switch with blower operating. If open, vacuum switch is defective. Replace. If OK, proceed to step 5. Reconnect leads to blower vacuum switch. |
| | | 5. Check for defective blower or blower relay. | <p>Check for defective blower:</p> <p>Disconnect blower plug from harness. Measure resistance across blower windings. Winding resistance across leads should be within the following range: Black-to-White: 30-45 ohms, Red-to-White: 90-130 ohms. If measured values differ substantially from these values, blower is defective. Replace.</p> <p>Check for defective blower relay:</p> <p>Disconnect high voltage plug from harness. Place heater in Pool or Spa mode. Lower set point temperature to generate call for heat. During pre-purge period, measure continuity across L1 and IND LO pins on control module. If open, blower relay on control module is defective. Replace control module.</p> |
| HS | Maximum return water temperature exceeded. | 1. Pool water temperature exceeds 108° F. | Verify set point setting of remote thermostat is below 108° F. If set point setting of remote thermostat is OK, or if heater is not configured for remote thermostat proceed to step 2. |
| | | 2. Verify that water flow is adequate. | Verify that water flow rate to heater is above minimum required (25 GPM for H250IDL, & 40 GPM for H400IDL). |
| HF | Flame sense fault. | 1. Flame sense failure. | Replace flame sense. |

Parts List


| ITEM NO. | PART NO. | DESCRIPTION |
|----------|------------|------------------------------|
| 1. | IDLJKT1250 | TOP JACKET ASY – H250IDL |
| 1. | IDLJKT1400 | TOP JACKET ASY – H400IDL |
| 2. | IDLBWR1930 | COMBUSTION BLOWER |
| 3. | IDLHXA1250 | HEAT EXCHANGER ASY – H250IDL |
| 3. | IDLHXA1400 | HEAT EXCHANGER ASY – H400IDL |
| 4. | IDLTRF1930 | TRANSFORMER |
| 5. | IDLVPS1930 | VENT PRESSURE SWITCH |
| 6. | IDLBVS1930 | BLOWER VACUUM SWITCH |
| 7. | IDLTMB1930 | TERMINAL BLOCK – 4 POLE |
| 8. | HAXPSA1930 | PRESSURE SWITCH ASY |
| 9. | IDLGSV0001 | GAS VALVE NATURAL |
| 9. | IDLGSV0002 | GAS VALVE PROPANE |
| 10. | IDLIGN1930 | IGNITOR |
| 11. | IDLBRN1930 | BURNER TUBE |
| 12. | IDLFLS1930 | FLAME SENSOR |
| 13. | HAXBON1930 | BURNER ORIFICE NATURAL GAS |
| 13. | HAXBOP1930 | BURNER ORIFICE PROPANE |
| 14. | HAXMAN1250 | GAS MANIFOLD – H250 |
| 14. | HAXMAN1400 | GAS MANIFOLD – H400 |
| 15. | IHXILS1930 | INTERLOCK SWITCH |
| 16. | IDLCPA1930 | CONTROL PANEL ASY |
| 17. | IDLWHM1930 | WIRE HARNESS MAIN |
| 18. | IDLWHH1930 | WIRE HARNESS HI-LIMITS |
| 19. | IDLURA1930 | UPPER RIGHT ACCESS COVER |
| 20. | HAXLRA1932 | LOWER RIGHT ACCESS COVER |
| 21. | IDLLAC1930 | LEFT ACCESS COVER |
| 22. | HAXBPI1930 | BY-PASS INSERT |
| 23. | HAXFCT1930 | FLOW CONTROL THERMOSTAT |
| 24. | CHXPLG1930 | 3/4" NPT BRASS PLUG |
| 25. | HAXBPV1930 | BY-PASS VALVE |
| 26. | HAXVSG1930 | VALVE SPRING |
| 27. | HAXSFT1930 | BRASS SHAFT |
| 28. | HAXADP1930 | BRASS ADAPTER |
| 29. | HMXHLI2931 | HIGH-LIMIT 135° F |
| 30. | HMXHLI2932 | HIGH-LIMIT 160° F |
| 31. | CHXDRV1930 | DRAIN VALVE ASY |
| 32. | CHXPSA1930 | PRESSURE SWITCH ADAPTER |
| 33. | CHXTBW1930 | BULB WELL |
| 34. | HAXFHD1931 | FRONT HEADER ONLY |
| 35. | HAXHOR1930 | HEADER O-RING |
| 36. | IHXPHK1930 | PLASTIC HARDWARE KIT |
| 37. | IDLTER1930 | THERMISTOR |

Parts Illustration

Order repair parts by item number and part description along with the model and serial number of the heater. The model and serial number will be found on the data plate.

Contact your pool/spa dealer, distributor, or Hayward Pool Products, Inc. for repair/replacement parts. Use Hayward parts only.

Figure 57



Hayward Pool Heater Certificate Of Limited Warranty

Limited heater warranty:

TERMS AND COVERAGE: We warrant our pool heater to be free from defects in workmanship and materials under normal use and service. Pursuant to this warranty and subject to the Conditions and Exceptions indicated below:

1. We will replace (cost of freight, installation, cost of fuel, and service labor at user's expense) with the prevailing comparable model, or, at our option, repair any pool/spa heater that leaks under normal use and service within two years from the date of original installation for single family residential users and one year for all other users.
2. In addition, we will replace (cost of freight, installation, cost of fuel, and service labor at user's expense) or, at our option, repair any part or parts of the pool/spa heater which malfunctions under normal use and service within two years from the date of original installation for single family residential users and one year for all other users.

LIMITATION ON IMPLIED WARRANTIES: WE ARE NOT LIABLE FOR ANY CONSEQUENTIAL DAMAGES FOR BREACH OF ANY WRITTEN OR IMPLIED WARRANTY OF THIS PRODUCT. Implied warranties, including the WARRANTY OF MERCHANTABILITY and all other implied warranties that may arise from course of dealing or usage of trade imposed on the sale of this heater under the laws of the state are limited in duration to the term of two (2) years for single family residential users and one (1) year for all other users. There are no warranties which extend beyond the description on the face hereof. We shall not in any event be held liable for any special, indirect, or consequential damages.

EXPENSE OF DELIVERY AND INSTALLATION: Each pool heater or replacement part to be furnished under this warranty shall be furnished at our nearest distribution center. We shall not pay, nor be responsible for shipping or delivery charges to the place of installation, nor for labor charges or other costs of removal or installation. Every defective heater or part replaced under this warranty shall become our property, and as such, must be returned to our distribution center with transportation charges paid by the user. Any replacement pool heater furnished under this warranty shall remain in warranty only for the unexpired portion of this warranty.

CONDITIONS AND EXCEPTIONS: This warranty applies only to the pool/spa heater at its original place of installation and only for the original owner. This warranty applies only to heaters installed for SINGLE FAMILY RESIDENTIAL APPLICATIONS. (Heaters installed for commercial, multi-family and other uses will be warranted for a period of one year from date of installation.) It does not apply if the pool heater is installed in violation of any applicable code or ordinance, or is not installed, operated and maintained in accordance with our instructions, or is misused,

damaged by accident, weather, act of God, freezing, water void and/or excess pressure, altered or disconnected. It does not apply with respect to:

1. A heater not equipped with Certified C.S.A. limit controls or equivalent pressure relief valve, installed in accordance with applicable ordinance;
2. A heater operated with settings in excess of, and/or with fuel not conforming to those shown on rating plate;
3. A heater on which the serial numbers have been altered, defaced, or removed;
4. Leaks arising from defective installation;
5. Production of noise, odors, or discolored (rusty, etc.) water;
6. Leakage substantially contributed to by sediment, lime precipitate and/or higher than normal dissolved solids (pH above 7.8) in the tank, copper tubes, or water ways;
7. Leakage substantially contributed to by corrosive elements in the atmosphere (such as the storage of chlorine or other chemicals);
8. Leakage caused substantially or contributed to by corrosive pool water in an acid condition (pH below 7.2);
9. Damage caused substantially or contributed to by an external source of energy;
10. A pool/spa heater is a water containing device. Leakage of water from this device can be expected at some time due to malfunction or the limitations of the service life of various components. Do not install this product where such leakage can cause damage. MANUFACTURER IS NOT RESPONSIBLE OR LIABLE FOR ANY COSTS INCURRED BY SUCH DAMAGE.

IN NO CASE ARE WE TO BE HELD LIABLE FOR DAMAGE TO SURROUNDING AREA OR PROPERTY CAUSED BY LEAKAGE OR MALFUNCTION.

HOW TO CLAIM UNDER THIS WARRANTY: The original owner, upon discovering the defect, must present the attached completed warranty claim card with proof of purchase either to the dealer or notify the Company in writing at either address:

Hayward Pool Products, Inc.
900 Fairmount Avenue
Elizabeth, NJ 07207

or
Hayward Pool Products, Inc.
2875 Pomona Boulevard
Pomona, CA 91768

Upon receipt of such notification we shall decide whether to repair such parts or replace any pool heater, reserving at all times the right to inspect in order to verify any claimed defect. We also reserve the right to have our representatives make any inspections, repairs, or to furnish replacements. This warranty is intended as a legally binding obligation of the Company, enforceable in the courts. This warranty may give you specific legal rights which may vary from state to state.

LIMITATION ON LIABILITY: All intended representations have been expressly set forth in this document. This warranty may not be extended by oral or any other additional representations, written sales information, drawings, or otherwise. Our liability, in the event of leakage or other malfunction, is strictly limited to repair or replacement of the defective heater or part, as provided herein and the Company is not responsible hereunder for incidental or consequential property damage or personal injury, interim loss of use of the heater, inconvenience or other consequential or incidental costs or damages. The Company neither assumes, nor authorizes any person or firm to assume for us, any further liability or obligation in connection with the sale, installation, use, maintenance, or existence of the heater.

SAFETY WARNING: Pool heaters are heat producing appliances and to avoid damage or injury in the event of possible overheating of the outer jacket (1) no materials should be stored against the jacket and (2) care should be taken to avoid unnecessary contact (especially by children) with the jacket. When lighting a gas heater, the lighting instructions must be followed exactly to prevent possible "flashback" of excess gas in the heater. Electronic ignition heaters and electric heaters must have the power shut off

when making adjustments to, servicing, or coming into contact with the heater. UNDER NO CIRCUMSTANCES SHOULD FLAMMABLE MATERIALS, SUCH AS GASOLINE OR PAINT THINNERS, BE USED OR STORED IN THE VICINITY OF THE HEATER OR IN ANY LOCATION FROM WHICH FUMES COULD REACH THE HEATER. For your comfort, enjoyment and safety, please read the enclosed operating instructions carefully.

FireTile™ five year limited warranty:

TERMS AND COVERAGE: This warranty is an extended limited warranty applicable to the FireTile™ components used in the combustion chamber of your pool/spa heater. All terms, conditions, limitations, and exceptions of the regular pool heater limited warranty remain in force, apply to this warranty, and are incorporated herein by reference.

Under the terms of this special FireTile™ limited warranty, we will replace (cost of freight, installation, cost of fuel, and service labor at user's expense) any components of your pool/spa heater made of FireTile™ which fail from defects in workmanship and materials under normal use and service in a single family residential application for a period of five (5) years.

Cut on line

USE THIS FORM ONLY FOR MAKING A CLAIM

LIMITED 2 YEAR POOL/SPA/HOT TUB HEATER CLAIM FORM

Model No. _____ Serial No. _____

Purchaser's Name _____

Installation Address _____

City/State/ZIP _____

Single Family Residential Use ☐ Yes ☐ No If no, fill in use _____

Dealer's Name _____

Address _____

Date of Installation _____

Note to Dealer: Fill in the following information on replacement heater.

Model No. _____ Serial No. _____ Date Installed _____

